Cell Use Instruction - MM.1S Cell Line

Product Info

Catalog	YC-B007	310	
Cell line	MM.1S		IBIGE
Morphology	Lymphoblastoid; Suspension growth and slight adherence	Passage ratio	1: 2-1: 4
Culture method	90%RPMI-1640+10%FBS Ubigene didn't use P/S. But client could use P/S after cells grow in good condition after thawing.		
Cryopreservation solution	50%RPMI-1640+40%FBS+10%DMSO		
Special Note	The adherent part of the cell can be directly blown down or digested and collected		

STR Authentication

	STR Info (Sample Cell)		STR Info (Cell bank)			
Loci	Sample Cell Line: MM.1S		Cell Line: MM.1S			
	Allele1	Allele2	Allele3	Allele1	Allele2	Allele3
D5S818	8	12	3)	8	12	
D13S317	13	13		13	13	- IBIGE
D7S820	10	11		10	11	
D16S539	12	12		12	12	
VWA	15	17		15	17	
TH01	7	8		7	8	
AMEL	Х	Х		X	Х	
ТРОХ	8	8	-11816	8	8	

+86 153 6067 3248 | US Toll free: 855 777 3210 | EU Toll free: 800 3272 9252 | Korea Toll free: 001 800 3272 9252

CSF1PO	9	14	9	14	
	-				

^{*} STR authentication data of this cell line matches with that of cell lines sourced from ATCC, DSMZ, JCRB, and RIKEN databases.

Conclusion: The STR identification of this cell is correct.

Cell Reception

Cryopreserved cells:

In the case of cryopreserved cells transported with dry ice, upon received, immediately transfer to liquid nitrogen for storage or store briefly at -80°C freezer, or proceed directly to cell thawing. Upon cell thawing, please count the cell number and cell viability and take some photos of the cells under different magnification (e.g. at 100x and 40x) as the records.

Notice: Upon received, please ensure to takes photos of the package, including dry ice and the tubes, and contact us within 24 hrs if any abnormalities such as dry ice has ran out, the cap of the cryovial is dislodged, broken and the cell is contaminated.

Cell Thawing

- 1) Preparation: warm up the complete culture medium in 37°C water bath for 30 mins. Transfer the cryopreserved vial from liquid nitrogen to 80°C freezer, and leave for several minutes to volatilize residual liquid nitrogen;
- 2) Inside the ultra-clean bench, pipet 6-7 mL of complete medium into a 15 mL centrifuge tube;
- 3) Take out the cryopreserved vial from 80°C freezer and leave in dry ice temporarily, shake slightly before thawing to remove residual dry ice and liquid nitrogen. Then hold the cap with forceps, quickly thaw cells in a 37°C water bath by gently swirling the vial (Note: keep the cap out of the water). In about 1 minute, it would completely thaw;

- 4) Inside the ultra-clean bench, sterilize the outer surface of the vial by wiping with an alcohol cotton pellet and leave it to dry. Transfer the thawed cells to the prepared centrifuge tube (step 2) by pipette, close the lid, and centrifuge at 1100 rpm for 4 mins at room temp to collect the cells;
- 5) Inside the ultra-clean bench, carefully remove and discard the supernatant. Resuspend cell pellet with 1mL of fresh complete medium and then transfer to a T25 flask (or 6 cm culture dish) containing 4 mL of complete medium, label the flask with cell name, date and passage no., incubate the flask in a 37°C, 5%CO2 incubator.

Note: Please do not thaw the cells directly to a T75 flask or 10 cm culture dish.

Cell Passaging

- 1) As long as the adherent cells are 80%-90% confluent, it is ready to passage.
- 2) Collect the suspension cells: Transfer the cell supernatant to the centrifuge tube on the ultra clean table.
- 3) Digest the adherent cells: Use 1×PBS (2-3 mL for T25 flask, 4-5 mL for T75) to briefly rinse the cell 1-2 times to remove residual medium and serum;
- 4) Add the corresponding volume of trypsin solution (see below table 1 for details) and allow trypsin completely cover the cells, place the flask into the incubator and incubate for 1-2 mins (If cells are hard to digest, allow appropriate extension of incubation), until the majority of the cells become round and non-adherent as observed under the microscope, a large number of cells detached from each side when gently shaking and tapping the flask, terminate trypsin digestion immediately;
- 5) Add complete medium to stop digestion, the volume is 2 times of trypsin. Then gently pipet the cells

several times to allow all cells to be completely detached from the flask;

- 6) Transfer the cell suspension with a 10 mL pipette into a 50 mL centrifuge tube, rinse the residual cells from the flask using appropriate volume of PBS, then collect and put them together to the centrifuge tube;
- 7) Centrifuge at 1100 rpm for 4 mins at room temp. After centrifugation, remove and discard the supernatant and resuspend the cells with 2 mL of complete medium;
- 8) Cells need to be passaged at appropriate passage ratio, 1:3 for the first passage, increasing the passaging ratio if the cells are grown to confluence within two days, or decreasing the passaging ratio if the cells are not grown to confluence in 3-4 days.

3) UBIGEN Table 1. Volume of Trypsin solution added to different size of culture plates/flasks

	Size of culture plates/flasks	Trypsin Volume added	
	6-well plate	0.5 mL	
	T25	1 mL	
	T75	2-3 mL	
	T175	3-4 mL	

Cell cryopreservation

- 1) Same as procedures of cell passaging, inside the ultra-clean bench, digest the cells to a single-cell suspension, and terminate digestion by adding complete medium. All liquid is transferred to a 50 mL centrifuge tube;
- 2) Mix well by pipetting and take 20 µL for cell counting;
- 3) Centrifuge at 1100 rpm for 4 mins at room temp. After centrifugation, remove and discard the

supernatant, and resuspend the cells with 1-2 mL of 4°C pre-cooled cryopreservation medium (use the one you usually use in lab, or any commercial cryopreservation solutions are fine), then add cryopreservation medium to adjust to the required density (1x10⁶-1x10⁷cells/mL);

- 4) Aliquot the cell suspension to cryovials as 1 mL/tube, close the lid tightly, and the cryovials should be labeled with the cell name, source, cell passage number, and date of cryopreservation in advance;
- 5) Place the cryovials in 4°C pre-cooled Freezing Container, then put the container in -80°C freezers within 15 mins after cell cryopreservation;
- 6) Stay overnight, transfer the cryovials to liquid nitrogen for long-term storage.

+86 153 6067 3248 | US Toll free: 855 777 3210 | EU Toll free: 800 3272 9252 | Korea Toll free: 001 800 3272 9252